

Columnas 50
 Colonnes 50
 Service poles 50
 Raumsäulen 50
 Colunas 50
 Colonne 50

Módulo
 Module
 Socket box
 Anbaumodul
 Módulo
 Modulo



Montaje
 Montage
 Assembly
 Montage
 Montagem
 Montaggio

Desmontaje
 Démontage
 Disassembly
 Demontage
 Desmontagem
 Smontaggio



IMD 5004.2

50123	= 1 x		+ 1 x		+ 2 x		+ 2 x	
50124	= 1 x		+ 1 x		+ 2 x		+ 2 x	
50144	= 1 x		+ 1 x		+ 2 x		+ 2 x	
50193	= 1 x		+ 1 x					
50194	= 1 x		+ 1 x					
50223	= 2 x		+ 4 x					
50224	= 2 x		+ 4 x					
50244	= 2 x		+ 4 x					
50293	= 2 x			50294 = 2 x				



